IB-200-W0688B-00　说明书/W688BT/出口/V1.0
尺寸：70x125mm 128克铜版纸双面过哑胶,黑色印刷，装钉

EDIFIER International Limited
www.edifier.com
© 2016 Edifier International Limited. All rights reserved.
Printed in China

NOTICE:

For the need of technical improvement and system upgrade, information contained herein may be subject to change from time to time without prior notice.

Products of Edifier will be customized for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product. If any difference is found, the actual product prevails.

Ver1.0　IB-200-W0688B-00

EDIFIER

W688BT

Stereo Bluetooth® Headphone

Operating instructions

■Overview

Before use the headphone, please carefully read this user manual and keep it for further reference.

Features

*High quality portable Bluetooth headphones featuring dynamic bass
*Bluetooth aptX
*Wireless distance up to 10m
*Low power consumption
*Up to 16 hours of playtime and standby 800 hours
*Integrated multi-function button for operating calls, music and volume

Specification

Bluetooth version	Bluetooth V4.1
Bluetooth protocol	HFP、HSP、A2DP、AVRCP
Effective distance	10m
Working time	16 hrs
Standby time	About 800 hrs
Charging input	DC 5.0V　500mA
Charging time	3 hrs
Battery capacity	430mAh Lithium ion Battery
Frequency response	10Hz-20KHz
Sensitivity (SPL)	100dB
Rated impedance	64 ohm

■ Instruction

1.Illustration



1	Left speaker	8	Charge port
2	Right speaker	9	Indicator
3	Adjustable headband	10	▲ key: previous track
4	NFC field	11	►II key: pause, play
5	Volume increase	12	▼ key: next track
6	Volume decrease	13	Microphone
7	MFB key (multi-function key)	14	AUX-in input port

Box content: Headphone x 1　storage box x 1　audio cable x 1
microUSB data charging cable x 1　User manual x 1

2. Recharging

During use, when you see red light flashing and have prompt tone every 5 minutes, it means the battery is low and you need to recharge the headphone.
Red light on = Charging
Red light off = fully charge
Recharging time: approx 3 hours.

Tips: W688BT headphone take a special design with short microUSB connect port based on the PCBA requirement, it is normal that the some plug part exposing out when in charging.

Warning: The rechargeable batteries providing power for the product must be properly disposed for recycling.
Do not place the batteries into fire to prevent explosion.

■ Headphone usage

1.On/Off

Function	Operation	Indicator
ON	Press and hold MFB key for about 3 seconds	Blue light lights for 1 second
OFF	Press and hold MFB key for about 3 seconds	Red light lights for 1 second

Note: If the headphone has no connection with any device after it is ON with 5 minutes, it will automatically turn off to save power.

2. Pairing/Connection

Pairing headphone with Bluetooth mobile

Steps are as below:
1. Make your mobile and the headphone keep closer. Press and hold MFB key about 5 seconds and release it when the blue and red light flash alternatively and have prompt tone. Now the headphone is in the pairing mode.
2. Enable your mobile Bluetooth function and search for Bluetooth devices. Select "EDIFIER W688BT" to pair and connect. When successfully connected, the blue light of the headphone flashes twice every 4 seconds and the headphone has prompt tone.
Note:
*the pairing mode maintains 2 minutes. If no device is paired over 2 minutes, the headphone will automatically switch to the standby mode.
* after the pairing is completed in the first time, the headphone will automatically connect the device being paired up last time.
* when the headphone connects no device after power on, press on any button allows the headphone to try to connect the device being connected last time.
* if the headphone gets away exceeding the connection distance and is disconnected, the connection will be resumed automatically if the headphone gets back to the effective connection distance in 5 minutes. Press on any button can start connecting if the time is over 5 minutes.

NFC connection

Please ensure that your mobile phone supports this function and in enable status.
Touch NFC field of the headphone and NFC field on the phone, the headphone will automatically connect to the phone.

Note:
1.you can't use the NFC pair connection function when the phone is in sleep or lock status.
2.Please touch headphone using phone until the headphone enter pairing mode when in the first pair connection.

Pairing and connecting with multiple devices

The headphone can connect with two Bluetooth devices at the same time. The operation is as below.
1. Firstly make the headphone pairs with the first device.
2. Re-start the headphone. Enter the pairing mode and pair with the second device.
3. Select connecting with the headphone from the first device. Now the headphone has already connected with the first and second device.

Note:
*Disable pairing one headphone with two devices: When the headphone stands by and connects with no device, press MFB key and volume decrease button about 2 seconds and release after hearing a prompt tone.
*Enable paring one headphone with two device: When the headphone stands by and connects with no device, press MFB key and volume increase button about 2 seconds and release after hearing a prompt tone.

3.Power display

When the headphone is connected with an iOS device, the headphone displays the current power in real time. When the power is low, the power symbol is in red to remind user to recharge the headphone.

Full power　Low power

4.Making call use headphone
Basic operations for making call

Functions	Headphone status	Operation
Cancel call	Calling	Press MFB key
Answer call	Incoming call	Press MFB key
Reject call	Incoming call	Press and hold MFB key about 2 seconds
End call	Talking	Press MFB key
Increase volume	Talking	Press or press and hold volume increase key
Decrease volume	Talking	Press or press and hold volume decrease key
Transfer call to mobile	Talking	Press and hold MFB key about 2 seconds
Transfer call to headphone	Talking	Press and hold MFB key about 2 seconds
Microphone muted	Talking	Double click MFB key
Mute off	Talking (Microphone muted)	Double click MFB key
Voice dial	Device connected	Press and hold ►II key about 2 seconds
Last number redial	Device connected	Double click MFB key

Three party call operation

Function	Headphone status	Operation
Answer new incoming call and end the current call	Talking and incoming the second call	Press ►II button
Answer new incoming call and reserve the current call	Talking and incoming the second call	Press and hold ►II button about 2 seconds
Reject new incoming call and continue the current call	Talking and incoming the second call	Double click ►II button
Switch call	Talking (reserved)	Press and hold ►II button about 2 seconds
End the current call and switch to the reserved call	Talking (reserved)	Press ►II button
End the reserved call and continue the current call	Talking (reserved)	Double click ►II button

Note:
*When the headphone is muted, you can hear the "beep" prompts every 10 seconds.
*For some mobiles, the call will be transferred prior to the mobile when the receive call button on the mobile is pressed, such as iphone. Now you can use the headphone's call switch or operate on your mobile to switch the call to the headphone.

Connect call from two mobiles

Function	Headphone status	Operation
Reserve the first mobile call and answer the second incoming call	The first call is going on and there is another incoming call	Press and hold ►II button about 2 seconds
End the first mobile call and answer the second incoming call	The first call is going on and there is another incoming call	Press ►II button
Reject the incoming call and continue the current call	The first call is going on and there is another incoming call	Double click ►II button
Switch call	Talking while one call is reserved	Press and hold ►II button about 2 seconds
End the current call and back to the reserved mobile call	Talking while one call is reserved	Press ►II button
End the reserved mobile call	Talking while one call is reserved	Double click ►II button

Play music

1. Bluetooth mode

Function	Headphone status	Operation
Increase volume	Play music	Press or press and hold volume increase key
Decrease volume	Play music	Press or press and hold volume decrease key
Previous track	Play music	Press▲button
Next track	Play music	Press▼button
Pause	Play music	Press►II button
Resume	Pause	Press►II button

Note:
● The remote play controls (Previous/Next/Pause/Resume) require your mobile or Bluetooth transmitter support AVRCP protocol. Please carefully read your mobile phone or Bluetooth emitter user manual.

2. AUX in audio mode
The headphone supports AUX in audio input, you can use the 3.5mm audio cable to switch it to wired headphone.

Note:
1. when the headphone is ON, plugging into the 3.5mm audio cable will let the headphone OFF and the Bluetooth connection will automatically disconnect, AUX in audio input is in failure.
2. if you want to use the Bluetooth function, please unplug the 3.5mm audio cable and turn ON the headphone again to re-connect the Bluetooth.
3. when the headphone is in AUX in input status and it is power off, the keys is disenable.

3. USB audio mode
The headphone can use USB data cable to connect to PC for playing music.

Note:
1. you must use the USB data cable to connect to PC for playing music, USB charging cable don't support for playing music on PC.
2. when you connect the headphone to PC in the first time, if the headphone have no output, you need to set the headphone as audio output device on PC.

■ Indicator

Indicator	Headphone status
Red and blue light flash alternately	Pairing
Blue light flashes once every 2 seconds	Disconnect device
Blue light flashes twice every 4 seconds	Connected device
Red light flashes instead of blue light	Low power

■ Restore factory settings

When the headphone is in standby and disconnects any device, press and hold MFB key and ►II button about 3 seconds until the red and blue light flash at the same time and headphone has prompt tone, then you can release the keys.
Note: After the factory settings are restored, the paired list of the headphone will be deleted. The headphone will enter the pairing mode automatically after being powered on again. If the headphone needs to connect any device, the new pairing is required.

■ Maintenance and repair

During usage, please read the following suggestions which would help you follow the warranty terms and make the product life longer.
● Keep the product dry and far from any damp places in order to avoid the affect on the product's internal circuit. You should avoid using the product during intense exercise or when you sweat too much.
● Do not place the product directly under the sun or where the temperature is high. High temperature will shorten the electronic components' life and damage batteries.
● Do not put the product at very cold places in order to prevent its internal circuit board from being damaged.
● Do not dismantle the product. Non-technician may damage the product.
● Do not drop, violently vibrate or strike the product with hard items in order to prevent its internal circuit from being damaged.
● Do not use strong chemical products or detergent to clean the headphone.
● Do not use any sharp items to scratch the product surface in order to prevent its casing from being damaged. and its outlook from being affected.
If the product cannot work properly, please send it to your qualified service organizations. The staff shall help you with their whole heart.

■ FAQs

1. The red light flashes instead of the blue light.
Answer: It means the headphone battery has low power. You need to recharge the headphone.
2. The red light is off when charging.
Answer: a. Please ensure the connection between the charging device and the headphone works well.
b. The batteries would be in the state of hibernate if the headphone is not in use for a long time. It needs to be recharged about 30 minutes. By then the red light will be on.
3. You cannot hear anything from the headphone.
Answer: a. Make sure the headphone is ON.
b. Make sure the headphone's volume is correct.
c. Make sure the headphone is properly connected with your mobile.
d. Make sure if the headphone is too far away from your mobile or there is any interfere device nearby.
4. The call quality is not good.
Answer: a. Make sure if your mobile is in the area having strong signal.
b. The effective work range of the headphone is 10 meters. Make sure the headphone is within the effective work range and there are no obstacles between the headphone and your mobile.
5. Why cannot the headphone pause, resume, go previous and next track when playing music.
Answer: These functions need the devices being paired with the headphone to support AVRCP protocol (Audio/Video Remote Control Profile).
6. It can't be use NFC for pairing connection.
a. make sure that the NFC function on the phone is enable.
b. you need to make the phone and headphone touch about 3 seconds until the red and blue light alternately flash, or it will be paired unsuccessfully.

Peringatan!

Untuk menjamin keselamatan diri Anda, jangan memakai atau menyimpan headphone di sekitar (dekat dari 10 cm) alat pacu jantung.

Jangan masukkan steker ke stopkontak listrik.

Awasi anak-anak saat menggunakan peralatan, produk ini bukan mainan.

Mendengarkan headphone pada tingkat volume tinggi – khususnya, selama waktu yang lama – dapat merusak pendengaran Anda.

Penggunaan sakelar pada sistem hi-fi Anda, atau penyumbatan pada headphone dapat menimbulkan klik yang pada pengaturan volume tinggi dapat memengaruhi pendengaran Anda.

Karena itu, selalu mengatur kontrol volume paling rendah sebelum beralih di antara berbagai sumber (penala, pemutar piringan hitam, pemutar CD, dll) atau penyumbatan pada headphone.

Untuk keselamatan lalu lintas, jangan gunakan headphone selama mengemudi atau berkendara.

تحذير!

لضمان سلامتك الشخصية، يرجى عدم ارتداء سماعات الرأس أو الاحتفاظ بها بالقرب من (أقرب من 10 سم) جهاز تنظيم ضربات القلب.

لا تُدخل القابس في مآخذ آهربائية.

احرص على الإشراف على الأطفال عند استخدام الجهاز، فالمنتج ليس لعبة.

الاستماع من خلال سماعات الأذن عند مستويات الصوت العالية، خاصة على مدى فترات طويلة، قد يضر بسمعك.

تشغيل المفاتيح في نظام واي فاي الخاص بك أو إدخال سماعات الرأس قد يسبب نقرات والتي قد تؤثر على سمعك في مستويات الصوت العالية.
لذلك، قم دائما بضبط زر التحكم في مستوى الصوت على الحد الأدنى قبل التبديل بين المصادر المختلفة (موالف، قرص دوار، مشغل أقراص مدمجة، الخ) أو عند توصيل سماعات الرأس.

من أجل السلامة المرورية، لا تستخدم سماعات الرأس أثناء القيادة أو رأوب الدراجات.

¡Atención!

Por su propia seguridad, procure no llevar ni guardar estos auriculares muy cerca de su marcapasos (a menos de 10cm).

No introducir el conector Jack en los casquillos conductores de corriente.

Vigile a sus hijos al utilizar el equipo. Este producto no es un juguete.

La utilización de auriculares a un volumen muy alto – sobre todo al utilizarlos durante largos períodos – puede conducir al deterioro del oído.

Al operar los interruptores de su sistema HiFi o al conectar los auriculares al sistema puede hacer clic, lo que a un volumen muy alto puede deteriorar el oído. Por lo tanto disminuya el nivel de volumen al mínimo al seleccionar entre diferentes fuentes (radio, tocadiscos, reproductor de CD ...) en su sistema HiFi o al conectar los auriculares.

Para no poner en peligro ni su capacidad de conducir, ni la seguridad de otros usuarios de la vía pública, no utilice en ningún caso sus auriculares al conducir un vehículo o al andar en bicicleta.

安全注意事項：

爲保證您的人身安全，請勿將該耳機佩戴或放置在離心臟起搏器過近的位置(小于10CM)。

請勿將插頭插入電源插座。

兒童應在成人監督下使用本設備，本產品并非玩具。

在高音量下使用耳機——特別是長時間使用——可能會對您的聽力造成損傷。

操作高保真音響開關或插入耳機時可能會發出尖利的聲音，其在高音量設置下可能會影響您的聽力。因此，在切換各種音源或插入耳機前，請將音量控制設置爲最低。

爲交通安全起見，駕駛時或騎自行車時請勿使用耳機。

Conseils de Sécurité!

Pour votre sécurité, ne portez pas et ne posez pas ce casque à proximité immédiate (moins de 10 cm) d'un pacemaker.

Ne pas introduire la fiche à jack dans des prises de courant.

Surveillez vos enfants s'ils utilisent l'appareil. Ce produit n'est pas un jouet.

Un casque d'écoute utilisé à un volume élevé risque de provoquer de troubles de l'audition, en particulier s'il est porté de façon prolongée.

Lorsque vous procédez à un réglage sur votre installation hi-fi ou que vous branchez le casque sur l'installation, des bruits dangereux pour l'oreille peuvent se produire si le son est réglé sur un volume élevé. Pour cette raison, il faut toujours mettre le son au minimum avant de passer d'une source à l'autre (radio, platine, lecteur de CD ...) ou de brancher le casque.

Pour ne pas mettre en danger votre sécurité au volant ni celle des autres usagers de la route, n'utilisez jamais le casque lorsque vous conduisez ou que vous roulez à vélo.

Attenzione!

Al fine di garantire la sicurezza personale, fare attenzione che queste cuffie non siano posizionate in prossimità del proprio eventuale pace maker (con una distanza inferiore a 10 cm).

Non introdurre la spina jack in una presa sotto tensione.

Sorvegliare i bambini quando utilizzano il dispositivo. Questo apparecchio non è un giocattolo.

L'utilizzo delle cuffie ad alto volume, soprattutto se prolungato, può danneggiare l'udito.

Maneggiare le manopole del Vostro sistema hi-fi o inserire le cuffie quando il volume è troppo alto, potrebbe produrre dei rumori che potrebbero danneggiare l'udito, soprattutto se il volume è alto. Si consiglia pertanto di regolare il volume al minimo prima di passare da una fonte all'altra (radio, giradischi, lettore CD, ecc.) o prima di collegare le cuffie.

Per la sicurezza nel traffico, si prega di non usare mai le cuffie mentre si guida o si va in bicicletta.

Warning!

To guarantee your personal safety, please do not wear or keep headphones in the vicinity (closer than 10cm) of a pacemaker.

Do not insert plug into electric sockets.

Supervise children when using the equipment, the product is not a toy.

Headphone listening at high volume levels – particularly, over extended periods of time – may damage your hearing.

The operation of switches on your hi-fi system or plugging in the headphones may cause clicks which at high volume setting may affect your hearing. Therefore, always set the volume control to minimum before switching between different sources (tuner, turntable, CD player, etc.) or plugging in the headphones.

For traffic safety, do not use headphones while driving or cycling.

安全指摘事項!

安全のために、このヘッドフオン-スメ-カ-の近く(10cm以内)で使用または保管することは避けてください。

差し込プラグをコンセントに差し込まないようにしてください。

お子様が使用になる場合は、 必ず大人が付き添えってください。本製品は玩具ではありません。

大きな音量のベッドフオンの使用は、特に長時間使用する場合において聴覚障害の原因となる恐れがあります。

HiFi機器の切り替え時、あるいは機器にヘッドフオンを接続する際に、音量が大きい場合にはガリガリという騒音が発生し、聴覚に悪影響を与える恐れがあります。
HiFi機器で各ソ-ス（ラジオ、レコードプレーヤ、CDプレーヤ. . .）を選ぶ際、あるいはヘッドフオンを接続する際には、音量のつまみを常に最少にしてください。

安全なドライブ、そして他の運転手の安全のためにも、お車を運転する場合、あるいは自転車に乗る場合にはヘッドヘオンは絶対に使用しないでください。

Sicherheitshinweis!

Um Ihre persönliche Sicherheit zu garantieren, achten Sie bitte darauf, dass dieser Kopfhörer nicht in nächster Nähe (näher als 10cm) zu Ihrem Herzschrittmacher getragen oder auf-bewahrt wird.

Klinkenstecker nicht in stromführende Buchsen einführen.

Beaufsichtigen Sie ihre Kinder bei der Benutzung des Geräts. Das Produkt ist kein Spielzeug.

Die Verwendung von Kopfhörern kann bei großer Lautstärke – vor allem im Dauerbetrieb – zur Schädigung des Gehörs führen.

Bei Umschaltvorgängen an Ihrer HiFi-Anlage oder bei Anschluss des Kopfhörers an die Anlage können Knackgeräusche auftreten, die bei hoher Lautstärke das Gehör beeinträchtigen.Drehen Sie daher den Lautstärkeregler immer auf Minimum, wenn Sie an Ihrer HiFi-Anlage zwischen verschiedenen Quellen (Radio, Plattenspieler, CD-Player ...) wählen oder den Kopfhörer anschließen.

Um Ihre Fahrtüchtigkeit und die Sicherheit anderer Verkehrsteilnehmer nicht zu gefährden, verwenden Sie Kopfhörer keinesfalls beim Lenken eines Kfz oder beim Radfahren.

경고!

안전상의 이유로,이 헤드폰은 심장박동 조절장치 근처(10cm 이내)에 두어서는 안됩니다.

잭 플러그를 전류가 흐르는 소켓에 삽입하지 마십시오.

어린이가 헤드폰을 사용할 때는 보호자의 주의 깊은 관찰이 필요합니다.이 제품은 장난감이 아닙니다.

헤드폰을 높은 볼륨상태에서 특히 장기간 사용할 경우 청각에 해가 될수 있습니다.

하이파이 오디오 시스템상에서 스위치를 바꾸거나 헤드폰을 하이파이 오디오 시스템에 연결할 경우,높은 볼륨상태에서는 청각에 해를 줄수 있는 클릭소리가 날수 있습니다.그러므로 하이파이 오디오 시스템상의 한 소스기기에서 다른 소스기기(라디오,레코드 플레이어,CD-플레이어...)를 선택하거나 헤드폰을 연결시킬 경우에는 항상 볼륨을 초저상태로 조정해 놓으십시오.

여러분의 운정상태와 다른 운전자들의 안전을 보호하기 위해 운정 중이거나 자전거를 타고 이동할 시에는 헤드폰 착용을 삼가 해 주십시오.

Предупреждение!

В целях гарантии вашей безопасности просим не надевать и не держать наушники вблизи (ближе 10 см) кардиостимулятора.

Запрещается вставлять штекер в электрические розетки.

При использовании прибора присматривайте за детьми, так как это оборудование не является игрушкой.

Прослушивание музыки через наушники на высокой громкости, особенно длительное время, может навредить вашему слуховому аппарату.

Включение и выключение переключателей на высококачественной системе воспроизведения или подключение наушников может привести к возникновению щелчков, которые на высокой громкости могут нанести вред вашему слуховому аппарату.
Таким образом, всегда устанавливайте громкость на минимальный уровень, прежде чем производить переключение между различными источниками (тюнер, диск проигрывателя, CD-проигрыватель и т.д.) или подключать наушники в систему.

Для безопасности дорожного движения не используйте наушники во время езды на велосипеде и вождения автомобиля.

Correct Disposal of this product. This marking indicates that this product should not be disposed with other household disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.