尺寸：55x75mm 128克铜版纸,黑色印刷，装钉

EDIFIER

W293BT

Bluetooth Stereo Headphones

Operating instructions

Thank you for using the stereo Bluetooth headphone W293BT.
Please carefully read this manual before using the product.

■ Features

- Designed like an oxygen tank, the W293BT is machined into shell form by a precision based metal powder process geared for optimum performance
- Supported by strong low-frequency output, this earphones is highly recommended for dynamic audio performance
- CSR chip with Bluetooth V4.1 supports AAC and Qualcomm® aptX™ audio decoding
- Dual batteries support up to 8 hours of continuous play
- IPX4 rating ensures water resistance at all times
- Connects up to 10m in distance
- Tilted in- ear design match multi-size earrings, silicone ear tips for comfortable wear
- Wired controller easily enables voice calls, volume adjustment and song changes

■ Specification

Bluetooth version: Bluetooth V4.1
Bluetooth protocol: HFP、HSP、A2DP、AVRCP
Audio decoding: Qualcomm® aptX™ audio decoding
Connecting distance: 10m
Working time: 8h
Charging time: 1.5h
Standby time: About 300h
Input: DC 5.0V ⎓ 500mA
Frequency response range: 20Hz-20KHz
Sound pressure level（SPL）: 105dB
Impedance: 24Ω

■ Box contents:

■ Function operational



■ Operation

1、Charging
Before the first use or the battery is in low level, please complete charging firstly.
1. Plug the USB charging cable into a PC's USB port.
2. Connect the charging cable to the headphone's micro USB charging port.

Red light on = Charging　　Red light off = fully charge

Charging time: It takes about 1.5 hours to do a fully charge.

Fully Charged

low battery level

Tips:
1. When Blue light quickly flashes thrice and headphone emit prompt per 3 minutes, it shows the battery is in low level, and just can supports 30 minute use.
2. In order to avoid shortening the battery life, please charge the headphone at least per 3 months when the headphone is un-use for a long time.

Warning: The rechargeable batteries of the headphone must be properly disposed for recycling. Never dispose of batteries in fire to avoid explosion.

2、ON/OFF

Function	Operation	Indicator
ON	Press and hold multi-function button for about 3 seconds	Blue light flashes quickly
OFF	Press and hold multi-function button for about 3 seconds	Red light flashes quickly

Tips
1. Under pairing status, the headphone will return to standby dormant status after 2 minutes without connecting successfully, you can press any key to start the operation under standby status.
2. The headphone will automatically turn off after 15 minute without any operation.
3. When the headphone disconnect due to over the effective distance, it will automatically re-connect if the headphone enter the connecting distance in 5 minutes, and will automatically turn off over 15 minutes.
4. When the headphone is in low battery level, it will automatically enter dormant state, and it will automatically be awaked and re-connect the near and paire mobile phones after starting to charge.

3. Pairing
1. Make the headphone enter into pairing mode according to the follow operation

Function	Operation	Indicator
Enter into pairing mode	Press and hold multi-function key for about 5 seconds	Red/blue light flash alternately

2. Keep your mobile and the headphone within 1 meter distance. The closer, the better.
3. Enable Bluetooth function on your mobile and search for Bluetooth devices.
4. Select "EDIFIER OXIGEN" to pair up and connect. When successfully connected, the blue light of the headphone flashes slowly.

Tips:
When under pairing process, please input "0000" when it needs pairing password.
After complete pairing, the headphone will automatically connect the last connected device in the next time use.

Connecting with two devices

1. Pair the headphone with the first device.
2. Re-start the headphone and enter pair status. Press and hold the multi-function key for about 5 seconds to enter the pairing settings, and pair with the second device.
3. Select connecting with the headphone from the first device. Now the headphone is connected with the first and second devices.

4. Making call via headphone

1. Basic operations

Functions	Headphone status	Operation
Answer call	Incoming call ringing	Press multi-function key
Reject call	Incoming call ringing	Press and hold multi-function key for about 2 seconds
Cancel Call	Calling	Press multi-function key
End call	Talking	Press multi-function key
Increase volume	Talking	Press + key
Decrease volume	Talking	Press - key
Mute	Talking	Press and hold – key for about 2 seconds
Cancel mute	Talking(muted)	Press and hold + key for about 2 seconds
Transfer call to mobile	Talking (headphone)	Press and hold multi-function key for about 2 seconds
Transfer call to headphone	Talking (mobile phone)	Press and hold multi-function key for about 2 seconds
Last number redial	Device connected and without call	Double press multi-function key
Voice dial	Device connected and without call	Press+/- keys at the same time

2. Three party call operation

Function	Headphone status	Operation
Answer new incoming call and end the current call	Incoming the second call	Press multi -function key
Answer new incoming call and put the current call on hold	Incoming the second call	Double press multi-function key
Switch call	Talking	Double click multi-function key
End the current call and switch to the on-hold call	Talking	Press multi -function key

3. Connect call from two mobiles

Function	Headphone status	Operation
End the first mobile call and answer the second incoming call	Another call comes in when you are on the first call	Press multi -function key
Put the first mobile call on hold and answer the second incoming call	Another call comes in when you are on the first call	Double press multi-function key
Switch call	Talking while one call is on hold	Double click multi-function key
End the current call and return to the on-hold mobile call	Talking while one call is on hold	Press multi -function key

Caution: Use for extended periods at high volume may affect your hearing capacity. Use product responsibly.
Tips:
1. When the volume of the headphone is set to its maximum, you will hear prompt.
2. Voice dial function just be useful for the mobile phone that has voice function assistant (such as siri of iPhone), and for the android mobile phone, it needs under un-lock status for use.
3. Press +/- keys at the same time when without conversation to enable the voice assistant function, again press +/- keys at the same time to disenable the voice assistant function.;

5. Play music

Function	Headphone status	Operation
Increase volume	Play music	Press + key
Decrease volume	Play music	Press - key
Previous track	Play music	Press and hold – key for about 2 seconds
Next track	Play music	Press and hold + key for about 2 seconds
Pause	Play music	Press multi-function key
Resume play	Pause to play music	Press multi-function key

■Maintenance and repair

Please read the following suggestions. These suggestions will help you stay in compliance with the warranty terms and prolong the product life.

- Keep the product dry and away from wet places to avoid moisture getting into internal circuit. Do not use the product during intense exercise or when you sweat too much.
- Do not place the product under directly the sunlight or near heat sources. High temperature will shorten the electronic components' life and damage batteries and cause certain plastic parts deformation.
- Do not put the product in very cold places in order to prevent its internal circuit board from being damaged.
- Do not dismantle the product. Non-technician may damage the product.
- Do not drop, violently vibrate or strike the product with hard items. It may cause damage to the circuit.
- Do not use strong chemical products or detergent to clean the headphone.
- Do not use any sharp items to scratch the product surface. It may damage the housing surface.

■FAQs

1. Red light flashes in place of blue light.
Answer: It tells that your headset battery is low and need to recharge.

2. The red light does not light up during charging.
Answer: a. Make sure the charge device connects to the headset properly.
b. The battery hibernates when the headset is not used for an extended period of time. In this case, it needs about 30 minutes of charge before the red light lighting up.

3. Don't hear anything in the headset.
Answer: a. Make sure the headset is set to a proper volume.
b. Make sure the headset has a valid connection with the mobile.
c. Make sure the headset is not too far away from the mobile and there is no interfering devices in vicinity.

4. Headset's call quality is bad.
Answer: a. Make sure the mobile is in a location with strong signal.
b. The headset has an effective working range of 10m. Please make sure the headset is within the working distance without obstacles between the headset and the mobile.

5. During playing, why the headset cannot perform controls over pause, resume, last song and next song.
Answer: The function requires that the device paired up with your headphones must support AVRCP (Audio/Video Remote Control Profile).

CAUTION

Danger of explosion if battery is incorrectly replaced.
Replace only with the same or equivalent type.

A warning that batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine,fire or the like.

1. "To prevent possible hearing damage, do not listen at high volume levels for long periods."
2. "Fully understand user manual before use."
3. "Ensure your player at low volume levels or power off before you leaving."

Correct Disposal of this product. This marking indicates that this product should not be disposed with other household disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Service Provision

Thank you for purchasing Edifier headset. To protect your rights, our company offers after-sales services as follows:

I. Helpdesk：If the user encounters any problem regarding use of the product, please feel free to call the following numbers for help: 8008105526 or 4008105526, or go to：www.edifier.com for information.
II. Warranty service: Warranty service does not include the shipping charges or costs for onsite support. Customers may go to any of our local after-sales service center to request for a 30-day no hassle exchange from the day of your purchase (provided no damage to the appearance of the product), or one year warranty service; in case there is no local after-sales service center nearby, the user may contact the manufacturer directly for service. For information, please call: 8008105526 or 4008105526. Upon receiving the confirmation for service from manufacturer's Customer Service, ship the product to its After-Sales department.
Note: Always call Customer Service for acceptance confirmation first before sending in the item.
III. Warranty does not cover headset damages resulting from any of the following reasons:

1. Improper use of the headset: causing headband or microphone boom wire broke, signal line broke, or headset housing crack.
2. Improper storage: Expose the headset to moisture for extended period of time. Have the speaker or microphone immersed in water.
3. Performed service without the company's authorization.

IV. Services will not be provided in case the warranty record does not match the actual product.
V. The warranty does not cover headset case, foam pad, or scratch on housing.
VI. Please bring this warranty card and valid purchase proof when you request for warranty service. Please keep this card and your valid purchase proof in a safe place. The warranty is void if the warranty card or purchase proof is altered.
VII. Before use, please read the operating instructions carefully.
VIII. The company reserves the right of final interpretation to the provisions of the after-sales service policy.

Beijing Edifier Technology Co., Ltd
Address: No. 68, the West Road of the 4th Northern Ring, Left Bank, Floor 8, West section, Haidian District, Beijing
Postal code: 100080

Dongguan Edifier Technology Co., Ltd (After-Sales Service)
Address: Engineering Department, Return Product Service Team, No. 2 East Industry Road, Edifier Industry Park, Songshan Lake High-tech Industrial Development District, Dongguan City
Telephone: 0769-88986868 (Use this number for shipping slip only. For after-sales service, please call 4008105526)
Postal code: 523808

EDIFIER

Warranty Card

Warranty Registration Contents

Product Name		Place Seal Here
Product Model		
Purchase Date		
User Name		
User Address		
Phone Number		
Service performed by		

DE Sicherheitshinweis!

Um Ihre persönliche Sicherheit zu garantieren, achten Sie bitte darauf, dass dieser Kopfhörer nicht in nächster Nähe (näher als 10cm) zu Ihrem.
Herzschrittmacher getragen oder auf-bewahrt wird.

Klinkenstecker nicht in stromführende Buchsen einführen.

Beaufsichtigen Sie Ihre Kinder bei der Benutzung des Geräts. Das Produkt ist kein Spielzeug.

Die Verwendung von Kopfhörern kann bei großer Lautstärke – vor allem im Dauerbetrieb – zur Schädigung des Gehörs führen.

Bei Umschaltvorgängen an Ihrer HiFi-Anlage oder bei Anschluss des kopfhörers an die Anlage können Knackgeräusche auftreten, die bei hoher Lautstärke das Gehör beeinträchtigen.Drehen Sie daher den Lautstärkeregler immer auf Minimum, wenn Sie an Ihrer HiFi-Anlage zwischen verschiedenen Quellen (Radio, Plattenspieler, CD-Player ...) wählen oder den Kopfhörer anschließen.

Um Ihre Fahrtüchtigkeit und die Sicherheit anderer Verkehrsteilnehmer nicht zu gefährden, verwenden Sie Kopfhörer keinesfalls beim Lenken eines Kfz oder beim Radfahren.

EN Warning!

To guarantee your personal safety, please do not wear or keep earphones in the vicinity (closer than 10cm) of a pacemaker.

Do not insert plug into electric sockets.

Supervise children when using the equipment, the product is not a toy.

Earphone listening at high volume levels – particularly, over extended periods of time – may damage your hearing.

The operation of switches on your hi-fi system or plugging in the earphones may cause clicks which at high volume setting may affect your hearing. Therefore, always set the volume control to minimum before switching between different sources (tuner, turntable, CD player, etc.) or plugging in the earphones.

For traffic safety, do not use earphones while driving or cycling.

CN 安全注意事項：

為保證您的人身安全，請勿將該耳機佩戴或放置在離心臟起搏器過近的位置(小于10CM)。

請勿將插頭插入電源插座。

兒童應在成人監督下使用本設備，本產品并非玩具。

在高音量下使用耳機——特別是長時間使用——可能會對您的聽力造成損傷。

操作高保真音響開關或插入耳機時可能會發出尖利的聲音，其在高音量設置下可能會影響您的聽力。因此，在切換各種音源或插入耳機前，請將音量控制設置為最低。

為交通安全起見，駕駛時或騎自行車時請勿使用耳機。

FR Conseils de Sécurité!

Pour votre sécurité, ne portez pas et ne posez pas ce casque à proximité immédiate (moins de 10 cm) d'un pacemaker.

Ne pas introduire la fiche à jack dans des prises de courant.

Surveillez vos enfants s'ils utilisent l'appareil. Ce produit n'est pas un jouet.

Un casque d'écoute utilisé à un volume élevé risque de provoquer de troubles de l'audition, en particulier s'il est porté de façon prolongée.

Lorsque vous procédez à un réglage sur votre installation hi-fi ou que vous branchez le casque sur l'installation, des bruits dangereux pour l'oreille peuvent se produire si le son est réglé sur un volume élevé. Pour cette raison, il faut toujours mettre le son au minimum avant de passer d'une source à l'autre (radio, platine, lecteur de CD ...) ou de brancher le casque.

Pour ne pas mettre en danger votre sécurité au volant ni celle des autres usagers de la route, n'utilisez jamais le casque lorsque vous conduisez ou que vous roulez à vélo.

IT Attenzione!

Al fine di garantire la sicurezza personale, fare attenzione che queste cuffie non siano posizionate in prossimità del proprio eventuale pace maker (con una distanza inferiore a 10 cm).

Non introdurre la spina jack in una presa sotto tensione.

Sorvegliare i bambini quando utilizzano il dispositivo. Questo apparecchio non è un giocattolo.

L'utilizzo delle cuffie ad alto volume, soprattutto se prolungato, può danneggiare l'udito.

Maneggiare le manopole del Vostro sistema hi-fi o inserire le cuffie quando il volume è troppo alto, potrebbe produrre dei rumori che potrebbero danneggiare l'udito, soprattutto se il volume è alto. Si consiglia pertanto di regolare il volume al minimo prima di passare da una fonte all'altra (radio, giradischi, lettore CD, ecc.) o prima di collegare le cuffie.

Per la sicurezza nel traffico, si prega di non usare mai le cuffie mentre si guida o si va in bicicletta.

ID Peringatan!

Untuk menjamin keselamatan diri Anda, jangan memakai atau menyimpan earphone di sekitar (dekat dari 10 cm) alat pacu jantung.

Jangan masukkan steker ke stopkontak listrik.

Awasi anak-anak saat menggunakan peralatan, produk ini bukan mainan.

Mendengarkan earphone pada tingkat volume tinggi – khususnya, selama waktu yang lama – dapat merusak pendengaran Anda.

Penggunaan sakelar pada sistem hi-fi Anda, atau penyumbatan pada earphone dapat menimbulkan klik yang pada pengaturan volume tinggi dapat memengaruhi pendengaran Anda.

Karena itu, selalu mengatur kontrol volume paling rendah sebelum beralih di antara berbagai sumber (penala, pemutar piringan hitam, pemutar CD, dll) atau penyumbatan pada earphone.

Untuk keselamatan lalu lintas, jangan gunakan earphone selama mengemudi atau berkendara.

NL Waarschuwing!

Om uw persoonlijke veiligheid te garanderen, dient de koptelefoon niet te worden bewaard of gedragen in de buurt van (minder dan 10 cm) een pacemaker. Steek de stekker in een stopcontact.

Houd toezicht op kinderen tijdens het gebruik van het apparaat; dit product is geen speelgoed.

Luisteren met de koptelefoon op hoog volume – met name gedurende een langere periode – kan leiden tot schade aan uw gehoor.

De bediening van de schakelaars op uw hifisysteem of het insteken van uw koptelefoon kan leiden tot harde klikgeluiden wat uw gehoor kan aantasten.

Om deze reden dient de volumeknop altijd op een minimum te worden geschakeld, voordat er tussen de verschillende bronnen (tuner, draaitafel, cd-speler, enz.) wordt geschakeld of de koptelefoon wordt aangesloten.

Met het oog op verkeersveiligheid dient de koptelefoon niet te worden gebruikt tijdens het rijden of fietsen.

KR 경고!

안전상의 이유로,이 헤드폰은 심장박동 조절장치 근처 (10cm 이내)에 두어서는 안됩니다.

잭 플러그를 전류가 흐르는 소켓에 삽입하지 마십시오.

어린이가 헤드폰을 사용할 때는 보호자의 주의 깊은 관찰이 필요합니다.이 제품은 장난감이 아닙니다.

헤드폰을 높은 볼륨상태에서 특히 장기간 사용할 경우 청각에 해가 될수 있습니다.

하이파이 오디오 시스템상에서 스위치를 바꾸거나 헤드폰을 하이파이 오디오 시스템에 연결할 경우,높은 볼륨상태에서는 청각에 해를 줄수 있는 클릭소리가 날수 있습니다.그리므로 하이파이 오디오 시스템상의 한 소스기기에서 다른 소스기기(라디오,레코드 플레이어,CD-플레이어...)를 선택하거나 헤드폰을 연결시킬 경우에는 항상 볼륨을 초저상태로 조정해 놓으십시오.

여러분의 운정상태와 다른 운전자들의 안전을 보호하기 위해 운정 중이거나 자전거를 타고 이동할 시에는 헤드폰 착용을 삼가 해 주십시오.

DK Advarsel!

For at garantere din personlige sikkerhed, skal du ikke bære eller holde hovedtelefonerne i nærheden (tættere end 10 cm) af en pacemaker.

Indsæt ikke stikket i stikkontakter.

Overvåge børn ved brug af udstyr, produktet er ikke legetøj.

Hovedtelefon lytte ved høje lydstyrker Navnlig glæder over længere perioder - kan høreskader.

Driften af kontakter på din hi-fi-system eller tilslutte hovedtelefonerne kan forårsage klik der på volumen indstilling højt kan påvirke høreIsen. Derfor altid indstiller lydstyrken til minimum, før der skiftes mellem forskellige kilder (tuner, pladespiller, CD-afspiller, etc.) eller tilslutte hovedtelefonerne.

For trafiksikkerheden, ikke anvendes under kørsel eller cykling.

ES ¡Atención!

Por su propia seguridad, procure no llevar ni guardar estos auriculares muy cerca de su marcapasos (a menos de 10cm).

No introducir el conector Jack en los casquillos conductores de corriente.

Vigile a sus hijos al utilizar el equipo. Este producto no es un juguete.

La utilización de auriculares a un volumen muy alto – sobre todo al utilizarlos durante largos períodos – puede conducir al deterioro del oído.

Al operar los interruptores de su sistema HiFi o al conectar los auriculares al sistema puede hacer clic, lo que a un volumen muy alto puede deteriorar el oído. Por lo tanto disminuya el nivel de volumen al mínimo al seleccionar entre diferentes fuentes (radio, tocadiscos, reproductor de CD ...) en su sistema HiFi o al conectar los auriculares.

Para no poner en peligro ni su capacidad de conducir, ni la seguridad de otros usuarios de la vía pública, no utilice en ningún caso sus auriculares al conducir un vehículo o al andar en bicicleta.

RU Предупреждение!

В целях гарантии вашей безопасности просим не надевать и не держать наушники вблизи (ближе 10 см) кардиостимулятора.

Запрещается вставлять штекер в электрические розетки.

При использовании прибора присматривайте за детьми, так как это оборудование не является игрушкой.

Прослушивание музыки через наушники на высокой громкости, особенно длительное время, может навредить вашему слуховому аппарату.

Включение и выключение переключателей на высококачественной системе воспроизведения или подключение наушников может привести к возникновению щелчков, которые на высокой громкости могут нанести вред вашему слуховому аппарату.
Таким образом, всегда устанавливайте громкость на минимальный уровень, прежде чем производить переключение между различными источниками (тюнер, диск проигрывателя, CD-проигрыватель и т.д.) или подключать наушники в систему.

Для безопасности дорожного движения не используйте наушники во время езды на велосипеде и вождения автомобиля.

SA تحذير!

لضمان سلامتك الشخصية، يرجى عدم ارتداء سماعات الرأس أو الاحتفاظ بها بالقرب من (أقرب من 10 سم) جهاز تنظيم ضربات القلب.

لا تدخل الفايس في مأخذ امريائية.

احرص على الإشراف على الأطفال عند استخدام الجهاز، فالمنتج ليس لعبة.

الاستماع من خلال سماعات الأذن عند مستويات الصوت العالية، خاصة على مدى فترات طويلة، قد يضر بسمعك.

تشغيل المفاتيح في نظام واي فاي الخاص بك أو إدخال سماعات الرأس قد يسبب نقرات والتي قد تؤثر على سمعك في مستويات الصوت العالية.

لذلك، قم دائما بضبط زر التحكم في مستوى الصوت على الحد الأدنى قبل التبديل بين المصادر المختلفة (مواقف، قرص دوار، مشغل أقراص مدمجة، الخ) أو عند توصيل سماعات الرأس.

من أجل السلامة المرورية، لا تستخدم سماعات الرأس أثناء

JP 安全指摘事項!

安全のために、このヘッドフオン-スメ-カ-の近く(10cm以内)で使用または保管することは避けてください。

差し込プラグをコンセントに差し込まないようにしてください。

お子様が使用になる場合は、必ず大人が付き添えってください。本製品は玩具ではありません。

大きな音量のヘッドフオンの使用は、特に長時間使用する場合において聴覚障害の原因となる恐れがあります。

HiFi機器の切り替え時、あるいは機器にヘッドフオンを接続する際に、音量が大きい場合にはガリガリという騒音が発生し、聴覚に悪影響を与える恐れがあります。HiFi機器で各ソース（ラジオ、レコードプレーヤ、CDプレーヤ...）を選ぶ際、あるいはヘッドフオンを接続する際には、音量のっまみを常に最少にしてください。

安全なドライブ、そして他の運転手の安全のためにも、お車を運転する場合、あるいは自転車に乗る場合にはヘッドヘオンは絶対に使用しないでください。

PL Ostrzeżenie!

Aby zapewnić sobie bezpiecze ń stwo, nie należy nosić ani trzymać słuchawek w pobliżu (w odległości mniejszej niż 10cm) od rozrusznika serca.

Nie wkładać wtyczki do gniazdka elektrycznego.

Nadzorować dzieci podczas korzystania ze sprzętu, produkt to nie zabawka.

Słuchanie w słuchawkach przy wysokich poziomach głośności, szczególnie przez długie okresy czasu, może spowodować uszkodzenie słuchu.

Działanie przełączników w systemie hi-fi lub podłączanie słuchawek mogą powodować mocne impulsy dźwiękowe, które przy dużej głośności mogą powodować pogorszenie słuchu.

Dlatego należy zawsze ustawiać głośność na minimalnym poziomie przed przełączaniem między różnymi źródłami dźwięku (tunerem, gramofonem, odtwarzaczem CD itp.) lub podłączeniem słuchawek.

Dla zachowania bezpiecze ń stwa jazdy nie należy używać słuchawek podczas prowadzenia samochodu czy jazdy na rowerze.

EDIFIER International Limited
www.edifier.com
© 2017 Edifier International Limited. All rights reserved.
Printed in China

NOTICE:

For the need of technical improvement and system upgrade, information contained herein may be subject to change from time to time without prior notice.

Products of EDIFIER will be customized for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product. If any difference is found, the actual product prevails.

Ver 1.0　IB-200-W0293B-00